



Wenzhou Safewire Electric Co.,Ltd.

2nd floor, Wealth Garden, Liushi Town, Yueqing city,Wenzhou,Zhejiang,China
Tel:0086-577-61725369; Email:info@safewirele.com;

www.safewirele.com

SPECIFICATION SHEET

PRODUCT NAME: CAT5E RJ45 sockets

PRODUCT No. : F22



ADD: 152 xinguang industrial zone, yueqing city, zhejiang province

(TEL) :0086-577-62799688

(E-mail): info@safewirele.com

(WEB): <http://www.safewirele.com>



Wenzhou Safewire Electric Co.,Ltd.

2nd floor, Wealth Garden, Liushi Town, Yueqing city,Wenzhou,Zhejiang,China
Tel:0086-577-61725369; Email:info@safewirele.com;

www.safewirele.com

Quick Details:

Description	RJ45 CAT5E
Model Number	F22
Size	45*22.5mm
Rated Voltage	110V-250V
Material	Panel: ABS; Inside part: Copper;Touch point : Silver alloy touch point
Color	White

Product Show:



Technical Characteristics:

1 Material characteristics

Contacts: gold/nickel, minimum thickness of gold > 0.8 μm

Metal parts: bronze, nickel, platinum, gold

PBT polycarbonate

For STP products the body and the spreader are made of metal alloy with a copper-nickel coating.

2 Electrical characteristics

Breakdown voltage 1000 V

Contact resistance $\leq 20 \text{ m}\Omega$

Insulation resistance 500 M Ω at 100 V DC

Connector tested and guaranteed under PoE restrictions, IEEE 802.3af standard and PoE+, draft standard 802.3at, up to 2500 on-load connections / disconnections.

Tests are carried out with 2 simultaneous PoE+ circuits for a minimum total power of 50 W.



Wenzhou Safewire Electric Co.,Ltd.

2nd floor, Wealth Garden, Liushi Town, Yueqing city,Wenzhou,Zhejiang,China
Tel:0086-577-61725369; Email:info@safewirele.com;

www.safewirele.com


3 Mechanical characteristics

Max. number of connections and disconnections: 5 without refreshing the wiring.

Endurance: 2500 movements (plug insertion/withdrawal).

IK03

Installation Instructions:



1. Strip off cable jacket to expose approximately 3/4" of wires.
2. Insert 2 pairs wires into the holes located on the top cover.
3. Close the top cover to snap firmly on the plug.
4. Take out the top cover and put another 2 pairs wire into the hole.
5. Close the top cover to snap firmly on the plug.




Wenzhou Safewire Electric Co.,Ltd.


2nd floor, Wealth Garden, Liushi Town, Yueqing city,Wenzhou,Zhejiang,China
Tel:0086-577-61725369; Email:info@safewirele.com;

www.safewirele.com


Connection:




Outline Drawing:



Real Life Scenarios:



Unlocking





SAFEWIRE


Wenzhou Safewire Electric Co.,Ltd.

2nd floor, Wealth Garden, Liushi Town, Yueqing city,Wenzhou,Zhejiang,China
Tel:0086-577-61725369; Email:info@safewirele.com;


www.safewirele.com

Usual connection of RJ 45:

RJ 45 connectors are equipped with a locking nut that does not require the use of a specific tool and which enables re-cabling in the event of error.



This system allows the wire pairs to be spread easily before mounting them on the connector.



Spreading cables ensures that each pair is separated by the specified 13 mm.

Spreading pairs by 90° in relation to the cable ensures optimum performance.



SAFEWIRE

Wenzhou Safewire Electric Co.,Ltd.

2nd floor, Wealth Garden, Liushi Town, Yueqing city,Wenzhou,Zhejiang,China

Tel:0086-577-61725369; Email:info@safewirele.com;

www.safewirele.com

RoHS Certificate of Compliance: Conforms with the Directive 2002/95/EC (ROHS)